PIP — Upload/Download System

The PIP upload/download system comprises a lead for connecting PIP to the micro and software on floppy disk.

This version of the PIP upload/download system allows users to:
  SAVE PIP programs on disk,
  LOAD PIP programs from disk to PIP,
  VIEW PIP programs on the computer screen,
  PRINT PIP programs.

This version of the software will work on BBC Model B micros and BBC Master 128 micros. One end of the lead plugs into the USER port underneath the micro and the other end plugs into the DIN socket on PIP.

Load the program with SHIFT/BREAK to display the instructions followed by a request to connect PIP and switch it on. At this point the screen MENU is displayed.

To save your PIP program on disk:

Choose 5 to read PIP. You will be asked to give your PIP program a name, for example, "MY FIRST PROGRAM". The name can have 32 characters including spaces. The PIP program is displayed on screen. Choose 4 to write your PIP program to disk. This saves your program on the disk automatically using your program name — "MY FIRST PROGRAM".

To use programs saved on disk with PIP:

Choose 3 to read program names on the disk. Select a program to display on screen.
Choose 6 to write the program on screen to PIP. Disconnect the lead before pressing GO on PIP.

Other MENU options:

Choose 1 and 2 to scroll up and down long PIP programs.
Choose 7 to see list of programs on the disk.
Choose 8 to print a program displayed on screen.

Prices and specification subject to change without notice.
DL11/07